

TOWN OF WESTPORT

BUILDING DEPARTMENT

CHECKLIST FOR PHOTOVOLTAIC POWER SYSTEM INSTALLATIONS

1. PV ARRAYS

- PV modules listed to UL Standard 1703 [110.3] {690.4(D)}
 - a. Mechanical Attachment
- Modules attached to the mounting structure according to the manufacturer's instructions [110.3(B)]
- Roof penetrations secure and weather tight
 - b. Grounding
- Each module grounded using the supplied hardware, the grounding point identified on the module and the manufacturer's instructions Note: Bolting the module to a "grounded" structure usually will not meet NEC requirements [110.3(B)]. Array PV mounting racks are usually not identified as equipment-grounding conductors
- Properly sized equipment-grounding conductors routed with the circuit conductors [690.45]
 - c. Conductors
- Conductor type - If exposed: USE-2, UF (usually inadequate at 60°C), or SE, 90°C, wet-rated and sunlight-resistant. [690.31 (B)] {2011 NEC restricts exposed single-conductor wiring to USE-2 and listed PV/Photovoltaic wire/cable} - If in conduit: RHW-2, THWN-2, or XHHW-2 90°C, wet-rated conductors [310.15]
- Conductor insulation rated at 90°C [UL -1703] to allow for operation at 70°C+ near modules and in conduit exposed to sunlight (add 17-20°C to ambient temperature - see Table 310.15(B)(2))
- Temperature-derated ampacity calculations based on 156% of short-circuit current (Isc), and the derated ampacity greater than 156% Isc rating of overcurrent device [690.8,9] Note: Suggest temperature derating factors of 65°C in installations where the backs of the module receive cooling air (6" or more from surface) and 75°C where no cooling air can get to the backs of the modules. Ambient temperatures in excess of 40°C may require different derating factors.
- Portable power cords allowed only for tracker connections [690.31 (C), 400.3,7,8]
- Strain reliefs/cable clamps or conduit used on all cables and cords [300.4, 400.10]
- Listed for the application and the environment

2. OVERCURRENT PROTECTION

- Overcurrent devices in the dc circuits listed for dc operation - if device not marked dc, verify dc listing with manufacturer - auto, marine, and telecom devices not acceptable.
- Rated at $1.25 \times 1.25 = 1.56$ times short-circuit current from modules [UL-1703, 690.8, module instructions] Note: Both 125% factors are now in the

NEC. Supplementary listed devices are allowed in PV source circuits only, but branch-circuit rated devices preferred. [690.9(C)].

- Each module or series string of modules have an overcurrent device protecting the module [UL-1703/NEC 110.3(B)] Note: Frequently, installers ignore this requirement marked on the back of modules. Listed combiner PV combiner boxes meeting this requirement are available. SMA Sunny Boy and some other "string" inverters operating at high voltages may not require dc fuses with two strings of modules or less. One or two strings of modules do not require overcurrent devices, but three strings or more in parallel will usually require an overcurrent device.
- Located in a position in the circuit to protect the module conductors from backfed currents from parallel module circuits or from the charge controller or battery [690-9(A) Informational Note]
- Smallest conductor used to wire modules protected - sources of overcurrent are parallel-connected modules, batteries, and ac backfeed through inverters. [690-9(A)]
- User-accessible fuses in "touch-safe" holders or capable of being changed without touching live contacts [690.16]

3. ELECTRICAL CONNECTIONS

- Pressure terminals tightened to the recommended torque specification
- Crimp-on terminals listed and installed with listed crimping tools by the same manufacturer
- Twist-on wire connectors listed for the environment (i.e. dry, damp, wet, or direct burial) and installed per the manufacturer's instructions
- Pressure lugs or other terminals listed for the environment (i.e. inside, outside, wet, direct burial)
- Power distribution blocks listed and not just UL Recognized
- Terminals containing more than one conductor listed for multiple conductors
- Connectors or terminals using flexible, fine-stranded conductors listed for use with such conductors?
- Locking (tool-required) on readily accessible PV conductors operating over 30 volts {690.33(C)}

4. CHARGE CONTROLLERS

- Charge controller listed to UL Standard 1741 [110.3] {690.4(D)}
- Exposed energized terminals not readily accessible
- Diversion controller has an independent backup control method [690. 72(B)(1)]

5. DISCONNECTS

- Disconnects listed for dc operation in dc circuits - automotive, marine, and telecom devices are not acceptable.
- PV Disconnect readily accessible and located at first point of penetration of PV conductors
- PV conductors outside structure until reaching first readily accessible disconnect unless in metallic raceway [690.14, 690.31 (F)]
- Disconnects for all current-carrying conductors of PV source [690.13]

- ❑ Disconnects for equipment [690.17]
- ❑ Grounded conductors not fused or switched - Bolted disconnects OK
Note: Listed PV Centers by Xantrex, Outback, and others for 12,24, and 48-volt systems contain charge controllers, disconnects, and overcurrent protection for entire dc system with possible exception of source circuit or module protective fuses.

6. INVERTERS (Stand-alone Systems)

- ❑ Inverter listed to UL Standard 1741 [110.3] {690.4(D)} Note: Inverters listed to telecommunications or other standards do not meet NEC requirements.
- ❑ DC input currents calculated for cable and fuse requirements - Input current = rated ac output in watts divided by lowest battery voltage divided by inverter efficiency at that power level. [690.8]
- ❑ Cables to batteries sized 125% of calculated inverter input currents [690.8(A)]
- ❑ Overcurrent/Disconnects mounted near batteries and external to PV load centers if cables are longer than 4-5 feet to batteries or inverter
- ❑ High interrupt, listed, dc-rated fuses or circuit breakers used in battery circuits - AIR/AIC at least 20,000 amps [690.71 (C), 110.9]
- ❑ No multiwire branch circuits where single 120-volt inverters connected to 120/240-volt load centers [100-Branch Circuit, Multiwire], [690.10(C)]

7. BATTERIES (None are listed)

- ❑ Building-wire type cables used [Chapter 3] Note: Welding cables, marine, locomotive (DLO), and auto battery cables don't meet NEC. Flexible, listed RHW or THW cables are available. Article 400 flexible cables larger than 2/0 AWG are OK for battery cell connections, but not in conduit or through walls. [690.74, 400.8] Flexible, fine stranded cables require very limited, specially listed terminals. See stand-alone inverters for ampacity calculations.
- ❑ Access limited [690.71 (B)]
- ❑ Installed in well-vented areas (garages, basements, outbuildings, and not living areas) Note: Manifolds, power venting, and single exterior vents to the outside are not required and should be avoided.
- ❑ Cables to inverters, dc load centers, and/or charge controllers in conduit
- ❑ Conduit enters the battery enclosure below the tops of the batteries [300.4] Note: There are no listed battery boxes. Lockable heavy-duty plastic polyethylene tool boxes are usually acceptable.

8. INVERTERS (Utility-interactive Systems)

- ❑ Inverter listed to UL Standard 1741 and identified for use in interactive photovoltaic power systems [690.4(D), 690.60] Note: Inverters listed to telecommunications and other standards do not meet NEC requirements.
- ❑ Backup charge controller to regulate the batteries when the grid fails [690.72(B)(1)]
- ❑ Connected to dedicated branch circuit with back-fed overcurrent protection [705.12]
- ❑ Listed dc and ac disconnects and overcurrent protection [690.15, 17]

- ❑ Total rating of overcurrent devices supplying power to ac load center (main breaker plus backfed PV breaker) less than load-center rating (120% of rating in residences) [705.12] The 2011 NEC allows the 120% breaker total on commercial installations if the PV breaker is at the opposite end of the busbar from the main utility breaker.

9. GROUNDING

- ❑ Only one bonding conductor (grounded conductor to ground) for dc circuits and one bonding conductor for ac circuits (neutral to ground) for system grounding [250] Note: The dc bonds may be located inside inverters or in ground-fault protection devices.
- ❑ AC and dc grounding electrode conductors connected properly - They may be connected to the same grounding electrode system (ground rod). Separate electrodes, if used, must be bonded together. [690.41,47] A combined dc grounding electrode conductor and an ac equipment-grounding electrode is allowed, but the conditions and requirements are numerous. {690.47}
- ❑ Equipment grounding conductors properly sized (even on ungrounded, low-voltage systems) [690.43]
- ❑ Disconnects and overcurrent in both of the ungrounded conductors in each circuit on 12-volt, ungrounded systems? [240.15(A)], [690.41]
- ❑ Bonding fittings used with metal conduits when dc system voltage is more than 250V dc [250.97]

10. CONDUCTORS (General)

- ❑ Standard building-wire cables and wiring methods used [300.1 (A)]
- ❑ Wet-rated conductors used in conduits in exposed locations [100 Definition of Location, Wet]
- ❑ DC color codes correct - They are the same as ac color codes-grounded conductors are white and equipment-grounding conductors are green, green/yellow, or bare. [200.6(A)]

TOWN OF WESTPORT
BUILDING DEPARTMENT
**CERTIFICATION FOR PHOTOVOLTAIC POWER SYSTEM
INSTALLATIONS**

(date)

Town of Westport
Office of the Building Official
515 Post Road East
Westport, CT 06880

RE: PHOTOVOLTAIC POWER SYSTEM INSTALLATIONS

To whom it may concern:

This letter is to certify that the photovoltaic power system installed at:

_____, Westport, CT
(Street address)

has been installed and tested as per the requirements of the 2018 Connecticut State Building Code, including the 2017 National Electrical Code (NFPA 70).

Sincerely,

(Signature)

(Your name)

(Your Company name)

(Your address)

(Your CT license type) *(Your CT license#)*

(CRS #)